


box where you can choose a specific color. The color number or the special color label is stored in the **DIMCLRD** variable.

**Linetype.** This drop-down list is used to set the linetype for the dimension lines.

**Lineweight.** This drop-down list is used to specify the lineweight for the dimension line. You can select the required lineweight by selecting it from this drop-down list. This value is also stored in the **DIMLWD** variable. The default value is BYBLOCK. Keep in mind that you cannot assign the lineweight to the arrowheads using this drop-down list.

**Extend beyond ticks.** The **Extend beyond ticks** (Oblique tick extension) spinner will be available only when you select the oblique, Architectural tick, or any such arrowhead type in the **1st** and **2nd** drop-down lists in the **Arrowheads** area. This spinner is used to specify the distance by which the dimension line will extend beyond the extension line. The extension value, entered in the **Extend beyond ticks** edit box, gets stored in the **DIMDLE** variable. By default, this edit box is disabled because the oblique arrowhead type is not selected.

**Baseline spacing.** The **Baseline spacing** (baseline increment) spinner is used to control the spacing between successive dimension lines drawn using the baseline dimensioning, see Figure 10-4. You can specify the dimension line increment to your requirement by specifying the desired value using the **Baseline spacing** spinner. The default value displayed in the **Baseline spacing** spinner is 0.38 units. This spacing value is also stored in the **DIMDLI** variable.



**Suppress.** The **Suppress** check boxes control the display of the first and second dimension lines. By default, both dimension lines will be drawn. You can suppress one or both the dimension lines by selecting their corresponding check boxes. The values of these check boxes are stored in the **DIMSD1** and **DIMSD2** variables.